





Amazon Fire TV Stick 설정 안내



1. Fire TV를 TV의 HDMI Input 단자에 연결합니다.
2. Fire TV 전원 USB 케이블을 연결하여 전원을 켭니다.
3. 티비 리모컨을 사용하여 티비의 Input 또는 Source 버튼을 눌러 Fire TV가 연결된 HDMI 단자를 선택하면 Fire TV 초기 설정 화면이 표시됩니다.




4. 리모컨과 Fire TV를 Paring하여 연결합니다.
5. Fire TV의 화면 안내에 따라서 와이파이를 설정하여 인터넷을 연결합니다.
6. PC에서 Amazon 계정에 로그인 합니다. 계정이 없으면 미리 amazon.com 웹사이트에서 계정을 만들어 놓습니다. 판매하는 기기에 이미 계정이 등록되어 있는 경우에는 아래와 같이 설정 화면에서 등록되어 있는 Amazon 계정 등록을 해지합니다.




7. PC에서 amazon.com/code 웹페이지에 로그인하여 화면에 표시되는 activation code를 입력합니다.







8. 코드 입력이 완료되면 환영 화면이 표시되고 기기 사용 준비가 완료됩니다.







9. Home 화면에서 'appstore' 앱스토어 아이콘을 실행하여 티비스마트 앱을 설치합니다.




10. 앱스토어에서 'tvsmart'로 검색하면 티비스마트 앱을 다운로드하여 설치할 수 있습니다.



11. 티비스마트 앱이 설치된 후에 홈 화면에서 모든 앱 관리 아이콘을 눌러서 티비스마트 앱을 홈 화면의 맨 앞으로 이동하면 홈 화면에서 티비스마트 아이콘이 표시됩니다.





12. 홈 화면에서 최근 사용 앱에서 티비스마트 앱을 실행할 수 있습니다.



Set Up Your Fire TV Stick

Connect your Fire TV to your TV and follow the on-screen instructions to complete setup.

1. Plug your Fire TV into your TV's HDMI port and then plug the power adapter into an outlet.
2. Use the USB cable to connect the power adapter and your Fire TV.
3. Put batteries in your Fire TV remote.
4. Turn on your TV and switch to the correct HDMI input.
5. If your remote doesn't pair automatically, press the **Home**  button until "Press  to start" appears on-screen (about 10 seconds).
6. Follow the on-screen instructions to connect to Wi-Fi and download the latest software update.
Note: If you're having issues with your Wi-Fi password, contact your internet service provider.
7. Sign in with your Amazon account. Use your mobile phone or computer to visit the on-screen web address (amazon.com.au/code) and enter the verification code.
8. Follow the on-screen questions to set up equipment control for devices like soundbars.


또 다른 설정 설명서,

<https://www.firesticktricks.com/how-to-set-up-amazon-fire-tv-stick-for-first-time.html>

<https://www.tomsguide.com/us/amazon-fire-tv-stick-guide,review-5594.html>

공장 초기화 방법

please factory reset your Fire TV device using the remote with these steps:

1. If needed, safely eject expandable storage.
2. Press and hold **Back**  and **right side of the navigation circle** together for 10 seconds.
3. On the TV screen, choose to continue or cancel the factory reset. If you don't choose, the device resets automatically after several more seconds.

***Please Note:** All account information and downloaded content is deleted during a factory reset.